
MTJZ Series MANUAL

MOUNTING


STEP 1

Motor with coupling

STEP 1: Attach the motor adapter on a preprepared location on the Linear Unit.



STEP 2: Place the coupling halves on the drive journal of the Linear Unit and the motor.




STEP 3: Ensure that the coupling halves and the drive journals are correctly aligned.



Tighten the screws on the coupling halves with the coupling tightening torque.

STEP 4: Insert the coupling spider into one of the coupling halves.

STEP 5: Attach the motor on the motor adapter with screws and join the coupling halves together at the same time.



♠

Maximum torque and the maximum speed of the motor must never exceed the limits of the Linear Unit!



i

For the tightening torques for the screws please refer to page number 1.005.0